


When the software of CNC router is NCstudio, first you need a desktop computer to plug PCI card, then please install it like follows,





1. Open "Ncstudio" file, and click  icon, install it step by step, choose default, please remember the position that installed Ncstudio.(when you install driver, please choose this file).




After finishing installation, it will produce a icon .


2. When you try to open it, it will pump "a hardware failure". You need to plug PCI card.






3. The computer will tell you “find a new hardware”, click it, install driver step by step, when you search software driver choose “Ncstudio” file, then position is as item 1 you remember the position that installed Ncstudio.



4. After installing driver, you can click the icon “”, open the software,




6. Import files into software, usually the format of file is “nc”. Below “Auto”, click the right button of mouse,




You also can import file as below,





7. After import file, set parameter as below,

a, if the CNC Router is 1325,




b, if the cnc router is 6090,


Start (mechanical) coor.	End (mechanical) coor.
X: 0 mm	X: 600mm
Y: 0 mm	Y: 900mm
Z: -80mm	Z: 0mm

About motor parameter,


X , Y, Z Axis all is 0.003125mm/plus.



8. You can control machine by manual in software and keyboard of computer.




In software




Keyboard

9. When you start the work, don't forget make XYZ in zero condition.



10. Press "start", and let machine work.



Hope these information can help you. Thanks