



Warning limited spacing in NC Studio control system


There are three conditions when warn limited space:

1. It touches the Iron materials

Limited spacing buttons are located in X,Y,Z axis separately. They are induction to Iron.







When machine works normally, limited spacing showing red in software, please refer to following picture:(you can find the spec in I/O states in software)

空闲

机械坐标	工件坐标	剩余距离
573.241	568.762	0.000
85.294	81.882	0.000
-128.481	60.687	0.000


进给速度(毫米/分钟)

设定值: 600
实际值: 100%

当前行(段)号: L3713


名称	引脚号	极性	序号
● 对刀	J1-01	N	0
● 限位	J1-06	N	1
● 限位	J1-07	N	2
● 限位	J1-08	N	3
○ 主轴低速	J1-12	N	0
○ 主轴中速	J1-13	N	1
○ 主轴高速	J1-05	N	2


When warning, it will become green.



For example, X axis limited spacing warning, X limited spacing button will become green.

When it warning, please find the operation in software and choose the last choice, its limit release






When the limited is released, move the machine left and right. It will be ok.

2. The warning light always flicker, you should consider two conditions:

1) checking all wires to see if there are any lose connection or any broken for wires.



2) If all wires connected well, please replace the warning light, its broken.



Above steps are related to limited spacing, when it happened, please do as the document.