

machine back home couldn't stop hitting


### **For cnc wood router M-1325 series**

When the machine back home ,the spindle couldn't stop hit

1. The limit switch is broken , if you use long time , the limit switch is easy broken ,because the spindle always hit it . So you need change a new limit switch




2. The limit switch wire connection ,maybe loose , maybe broken ,please check the wire connection



**For mini desktop cnc router ,RS-3040,RS-4060,RS-6090**

When the machine back home ,the spindle couldn't stop hit

1.The limit switch is broken , if you use long time , the limit switch is easy broken ,because the spindle always hit it . So you need change a new limit switch



2.The limit switch wire connection ,maybe loose , maybe broken ,please check the wire connection



Redsall